



**NOTES:**

1. BUSHING SHALL BE USED AT END OF CONDUIT.
2. TAPE DETECTOR CONDUCTORS OR CABLES 3" EACH SIDE OF BUSHINGS.
3. INSTALL DUCT SEAL COMPOUND TO EACH END OF TERMINATION CONDUIT BEFORE INSTALLING HOT MIX ASPHALT.
4. ROUND ALL SHARP EDGES WHERE DETECTOR CONDUCTORS OR CABLES HAVE TO PASS.
5. END OF CONDUIT SHALL BE 3" BEYOND THE LIP OF GUTTER.
6. 

<u>CONDUIT SIZE</u>	<u>LOOP CONDUCTORS</u>
1" C MINIMUM	1 TO 2 PAIRS
1 1/2" C MINIMUM	3 TO 4 PAIRS
2" C MINIMUM	5 OR MORE PAIRS
7. SPLICE DETECTOR CONDUCTORS OR CABLES TO DETECTOR LEAD-IN-CABLE.
8. KEEP LOOP WIRE IN SAND AREA TO PROTECT FROM QPR 50-LB ASPHALT PATCH.



CURB TERMINATION DETAIL

	CITY OF CLOVIS				DWG NO. <b>TS-2</b>
	LOOP DETECTOR PLACEMENT				REF.: STANDARD SPEC. SECTION 86
APPROVED BY:	NO.	REVISED	BY	APPROVALS	SCALE: NTS
CITY ENGINEER		04-14-09	BGJ	CM DRU PUD	DRAWN BY: JA
	DATE: 5/19/2020	3	01-18-11		BGJ
		10-07-19	CGV		